
CRONO Super PID Ambulatory Infusion Pump




ABBREVIATED USER GUIDE

Keep buttons depressed for a few seconds to activate commands. When the pump is locked the syringe symbol blinks.



PREPARATION OF THE SYRINGE



WARNING SIGNALS

Warnings are accompanied by audible signals.

WARNING SIGNALS	DESCRIPTION	ACTION
20 E	Unfeasible operation	··
20 E 1	INCORRECT RESET	RESTART DEVICE*
20 Er. 2	CRITICAL CONDITION OF THE SECURITY SYSTEM	Press button +
[20 _E]	IRREGULARITY OF THE MOTOR CIRCUIT	Press button (+)
20 E '4	MECHANICAL BLOCK DURING "END" PHASE CAUSED BY FOREIGN MATTER OBSTRUCTING THE PUSHER'S REVERSAL	1. Remove the cause 2. Restart device*
20 Er. 5	IRREGULARITY OF THE PUSHER ADVANCEMENT	Press button
20	Occlusion	Press button +
20 Er. B	READING MEMORY ERROR (EEPROM)	Restart device*
20 E F. 9	ERROR WITHIN THE MOTOR PILOTING CIRCUIT	RESTART DEVICE*
20 E r. <u>d</u>	UNFEASIBLE OPERATION P BUTTON LOCKED	REFER TO USER GUIDE
20 1	Unfeasible operation pump locked	

* To restart the device after an alarm message, remove the battery and wait at least 15 seconds before replacing the battery.

If the device will not re-start, contact your authorized distributor.

Distributor:

Intra Pump Infusion Systems 401 Southwestern Blvd., Suite 160, Coppell, TX 75019

Tel: 866-211-7867 - Fax: (630) 845-2768 www.intrapump.com

Manufacturer:

CANÈ S.p.A. Via Cuorgnè, 42/a - 10098 Rivoli Torino, Italy www.canespa.it

